



ISOPRENE VI

Isoprenic /vinyl polymeric retanning agent with excellent filler properties for empty leather.

COMMERCIAL LABORATORY

ASA Industria Química Ltda

453, Adolfo Otto Koch St.

Neighborhood: Das Rosas

City: Estância Velha

State: Rio Grande do Sul

Zip Code: 93602-100

Phone: +55 (51) 3561-9736 / +55 (51) 997-265-261 – Mr. Aldo Stella

E-mail: asachemical@gmail.com

aldost2001@gmail.com

CHEMISTRY FEATURE

| | |
|-------------------------------|--------------|
| Aspect: | Viscous |
| Color: | Almost white |
| Light fastness: | Very good |
| Acid stability: | Good |
| Electrolyte stability: | Good |
| Active matter: | 12% +/- 2% |
| pH (10%): | 6,0 +/- 0,5 |
| Charge: | Anionic |

PRODUCT CHARACTERISTICS

ISOPRENE VI has a very good filling effect, with a rubbery touch, maintaining the firmness and appearance of the grain. The product is particularly suited for the retanning of loose leathers and skins. It is generally applied in combination with synthetic, vegetable retanning agents, and gets great results used in conjunction with **ISOPRENE FSU**.

ISOPRENE VI is stable in production baths with pH above 3.5. Does not affect water repellent properties and can be used in retanning systems for highly water repellent leathers.

ISOPRENE VI is very suitable for the retanning of light and heat resistant leathers, automotive upholstery.

APPLICATIONS

ISOPRENE VI can be used alone or in conjunction with **ISOPRENE FSU** giving a synergistic result and giving the leather an optimal fill and firmness, or it can be used with synthetic and vegetable in the amount of 3.0 - 5.0% **ISOPRENE VI** (% calculated on lowered weight).

After neutralization during retanning; 2.0 - 4.0% **ISOPRENE VI** (% calculated on lowered weight).

It is suggested to use **ISOPRENE VI** in combination with **ISOPRENE FSU** in the amount of 50% each, both weighed, diluted and added together.

The above descriptions correspond to our current level of knowledge and experience. These constitute some advice without commitment and we ask you to adapt them to your particular work.

Unsere Angaben sind unverbindlich; den örtlichen Verhältnissen angepasst und fachrichtig angewendet sind sie zuverlässig.

Les indications ci-dessus n'engagent pas notre responsabilité; elles sont sûres si on les adapte aux conditions locales et si l'application est correctement exécutée.

The foregoing data are given without engagement; they are, however, reliable if applied correctly and adapted to local conditions.



ISOPRENE VI

Isoprenic /vinyl polymeric retanning agent with excellent filler properties for empty leather.

Eg.: 3% **ISOPRENE VI** + 3% **ISOPRENE FSU** diluted together and added to the drum with a 60 minute rotation. After, follow with normal process.

The above descriptions correspond to our current level of knowledge and experience. These constitute some advice without commitment and we ask you to adapt them to your particular work.

Unsere Angaben sind unverbindlich; den örtlichen Verhältnissen angepasst und fachrichtig angewendet sind sie zuverlässig.

Les indications ci-dessus n'engagent pas notre responsabilité; elles sont sûres si on les adapte aux conditions locales et si l'application est correctement exécutée.

The foregoing data are given without engagement; they are, however, reliable if applied correctly and adapted to local conditions.